

Zigbee门窗磁传感器英文说明书

TECHNICKÁ SPECIFIKACE: Barva: černá Baterie: 3V CR2032 Protokol: ZigBee 3.0 Frekvence: 2400MHz~2483.5MHz Maximální RF výstupní výkon: ZigBee:10dBm - max 19dBm Dosah: 30m v otevřeném prostoru Pohotovostní proud: <5uA Pracovní proud: <60mA Pracovní teplota: -10 až +55°C Životnost baterie: 2 roky (10krát denně) Rozměry: délka: 54 / 34 mm šířka: 24 / 10 mm výška: 12 / 12 mm PÁROVÁNÍ MAGNETICKÉHO SENZORU IMMAX NEO S APLIKACÍ IMMAX NEO Poznámka: Ve verzích aplikace pro Android a iOS můžete narazit na drobné nesrovnalosti, například mírně odlišné příznaky nebo ikony, ale princip fungování je stejný Aktualizace firmwaru může mít za následek změny na funkčnost aplikace.	ZPROVOZNĚNÍ 1. Pomocí resetovací jehly stiskněte a podržte resetovací tlačítko Magnetického senzoru po dobu delší než 5 vteřin, dokud nezačne blikat LED indikátor. 2. Vše je připravené na párování. 3. Otevřete aplikaci Immax NEO PRO. 4. Klikněte na ikonu „Místnost“. 5. Klikněte na ikonu „+“ pro přidání nového zařízení. 6. V levém sloupečku vyberte kategorii Immax NEO. 7. Z nabízených produktů zvolte Magnetický senzor – zigbee. 8. Zvolte chytrou bránu, se kterou chcete toto zařízení spárovat (poznámka: toto je nezbytné, pokud máte víc než jednu chytrou bránu Immax NEO PRO). 9. Klikněte na ikonu „Další krok“. 10. Potvrďte, že LED dioda bliká. 11. Klikněte na ikonu „Další krok“. 12. Vyčkejte, až bude zařízení řádně spárované s chytrou bránou Immax NEO PRO. 13. Zadejte název zařízení. 14. Zvolte místnost, ve které chcete mít dané zařízení umístěné. 15. Klikněte na „Dokončeno“.	RESET MAGNETICKÉHO SENZORU IMMAX NEO Pomocí resetovací jehly stiskněte a podržte resetovací tlačítko Magnetického senzoru po dobu delší než 5 vteřin, dokud nezačne blikat LED indikátor. BEZPEČNOSTNÍ INFORMACE UPOZORNĚNÍ: Uchovávejte mimo dosah dětí. Tento výrobek obsahuje malé součástky, které mohou způsobit udušení nebo zranění při požití. VAROVÁNÍ: Každá baterie má předpoklad k úniku škodlivých chemikálií, které mohou poškodit pokožku, oděv nebo prostor kde je baterie uložena. Abyste předešli riziku zranění, nedovolte aby jakákoliv látka z baterie přišla do kontaktu s očima nebo pokožkou. Každá baterie může prasknout či dokonce explodovat pokud je vystavena ohni nebo jiným formám nadměrného tepla. Během manipulace s bateriemi buďte opatrní. Pro snížení rizika či zranění způsobené nesprávným zacházením s bateriemi proveďte následující opatření: - Nepoužívejte různé značky a typy baterií ve stejném zařízení - Při výměně baterií vždy vyměňte všechny baterie v zařízení - Nepoužívejte dobíjecí nebo opakovaně použitelné baterie. - Nedovolte dětem instalovat baterie bez dohledu.	- Dodržujte pokyny výrobce baterie pro správnou manipulaci a likvidaci baterie. UPOZORNĚNÍ: Výrobek a baterie by měly být likvidovány v recyklačním centru. Nevyhazujte s běžným odpadem z domácnosti. UPOZORNĚNÍ: Pro zajištění bezpečného používání výrobku je nutné v místě instalace přivést vodiče dle platných předpisů. Instalace musí být provedena pouze osobou s odpovídající certifikací v oboru elektro. Při montáži nebo při zjištění závady, musí být vždy odpojený přírodní kabel ze zásuvky (v případě přímého zapojení je nutné vypnout příslušný jistič). Nesprávná instalace může vést k poškození výrobku a zranění. UPOZORNĚNÍ: Neprovádějte demontáž výrobku, možnost úrazu elektrickým proudem. UPOZORNĚNÍ: Používejte pouze originální napájecí adaptér dodaný s výrobkem. Nevuádějte zařízení do provozu, pokud přírodní kabel vykazuje známky poškození. UPOZORNĚNÍ: Postupujte podle pokynů v příloženém manuálu. ÚDRŽBA Chraňte zařízení před kontaminací a znečištěním. Přístroj otřete měkkým hadříkem, nepoužívejte drsný nebo hrubozrnný materiál.	NEPOUŽÍVEJTE rozpouštědla nebo jiné agresivní čističe či chemikálie. Na tento výrobek bylo vydáno Prohlášení o shodě, více informací naleznete na www.immax.cz Zkrácená verze prohlášení o shodě Tímto výrobcem IMMAX prohlašuje, že typ rádiového zařízení 07560L je v souladu se směrnicí 2014/53/EU. Úplné znění EU prohlášení o shodě je k dispozici na těchto internetových stránkách www.immax.cz, www.immax.eu Bezpečnostní informace k tomuto výrobku si můžete stáhnout ze stránek www.immax.cz. Pokud máte dotaz nebo potřebujete poradit, kontaktujte nás na adrese podpora@immaxneo.cz. Poznámky Symbol  vyjadřuje, výrobek nesmí být likvidován s komunálním odpadem. Pro správnou likvidaci výrobku jej odevzdejte na určených sběrných místech. Při likvidaci vyměňte za zařízení baterie a žárovky – pokud to lze. Starý spotřebič odevzdvívejte ve sběrnách k tomu určených, nepatří do komunálního odpadu. Odpadní elektronika a elektronická zařízení ze soukromých domácností lze zdarma odevzdat na veřejných sběrných místech Jako koncový uživatel odpovídáte za výmaz osobních údajů ze starého spotřebiče ASEKOL: AK-016010, WEEE-Reg.-Nr. DE 88927148	 Immax neo Smart Home Devices Immax NEO Smart magnetický senzor na dveře a okna, Zigbee 3.0, černý UŽIVATELSKÝ NÁVOD  Výrobce: IMMAX, Teslova 1179/2, 702 00 Ostrava, EU www.immax.cz Vyrobeno v P.R.C.
---	--	--	--	---	---

TECHNICAL SPECIFICATIONS: Colour: black Battery: 3V CR2032 Protocol: ZigBee 3.0 Frequency: 2400MHz~2483.5MHz Maximum RF output power: ZigBee:10dBm - max 19dBm Range: 30m in open area Standby current: <5uA Operating current: <60mA Operating temperature: -10 to +55°C Battery life: 2 years (10 times a day) Dimensions: Length: 54/34mm Width: 24 / 10 mm Height: 12 / 12 mm PAIRING THE IMMAX NEO MAGNETIC SENSOR WITH THE IMMAX NEO APP Notes: In the Android and iOS versions of the app, you may encounter minor discrepancies, such as slightly different commands or icons, but the principle of operation is the same. Firmware updates may result in changes to the functionality of the app.	DISCLAIMER 1. Using the reset needle, press and hold the Magnetic Sensor reset button for more than 5 seconds until the LED indicator starts flashing. 2. Everything is ready for pairing. 3. Open the Immax NEO PRO app. 4. Click on the "Room" icon. 5. Click on the "+" icon to add a new device. 6. Select the Immax NEO category in the left column. 7. Select Magnetic sensor - zigbee from the available products. 8. Select the smart gateway you want to pair this device with (note: this is necessary if you have more than one Immax NEO PRO smart gateway). 9. Click on the "Next Step" icon. 10. Confirm that the LED is flashing. 11. Click on the "Next Step" icon. 12. Wait until the device is properly paired with the Immax NEO PRO smart gateway. 13. Enter the device name. 14. Select the room where you want the device to be located. 15. Click on "Done".	IMMAX NEO MAGNETIC SENSOR RESET Using the reset needle, press and hold the Magnetic Sensor reset button for more than 5 seconds until the LED indicator starts flashing. Safety Information CAUTION: Keep out of reach of children. This product contains small parts, which may cause suffocation or injury if swallowed. WARNING: Every battery has the potential to leak harmful chemicals that can damage skin, clothing or area where the battery is stored. To avoid the risk of injury, do not allow any substance from the battery to come into contact with the eyes or skin. Every battery may burst or even explode if exposed to fire or other forms of excessive heat. Take care when handling the batteries. To reduce the risk of injury from mishandling the batteries, take the following precautions: - Do not use different brands and types of batteries in the same device - When replacing the batteries, always replace all the batteries in the device - Do not use rechargeable or reusable batteries. - Do not allow children to insert batteries without supervision. - Follow the battery manufacturer's instructions for proper battery handling and disposal. CAUTION: The product and batteries should be disposed of at a recycling centre. Do not dispose of them with normal household waste. CAUTION: To ensure safe use of the product, wires must be brought at the installation site according to valid regulations. The installation must only be carried out by an individual with the appropriate certification in the field of electronics. During installation or when a fault is detected, the power cable must always be disconnected from the socket (in the case of direct connection, the relevant circuit breaker must be switched off). Improper installation can damage the product and cause injury. CAUTION: Do not disassemble the product, electric shock may occur. CAUTION: Use only the original power adapter provided with the product. Do not operate the device if the power cord shows signs of damage. CAUTION: Follow the instructions in the enclosed manual. MAINTENANCE Protect the device from contamination and soiling. Wipe the device with a soft cloth, do not use rough or coarse materials.	DO NOT USE solvents or other aggressive cleaners or chemicals. A Declaration of Conformity has been issued for this product, more information can be found at www.immax.cz Short version of the Declaration of Conformity The manufacturer IMMAX hereby declares that type 07560L radio equipment complies with Directive 2014/53/EU. The full text of the EU Declaration of Conformity is available on the following websites: www.immax.cz, www.immax.eu Safety information for this product can be downloaded from www.immax.eu. If you have any questions or need advice, please contact us at podpora@immaxneo.cz. Notes The symbol  indicates the product must not be disposed of with municipal waste. To dispose of the product properly, take it to the designated collection points. When disposing of it, remove the batteries and bulbs behind the device - if possible. Dispose of old appliances at designated collection points; they do not belong in municipal waste. Waste electrical and electronic equipment from private households can be handed in free of charge at public collection points As the end user, you are responsible for deleting personal data from the old appliance ASEKOL: AK-016010, WEEE-Reg.-No. DE 88927148	 Immax neo Smart Home Devices Immax NEO Smart magnetic door and window sensor, Zigbee 3.0, black USER MANUAL  Manufacturer: IMMAX, Teslova 1179/2, 702 00 Ostrava, EU www.immax.cz Made in P.R.C.
--	--	--	--	---